

ADAM™

SUPPLEMENT NO. 42674

SUPPLEMENT INSTRUCTIONS

INSERTING AND REMOVING DIGITAL DATA PACKS


Your digital data drive may have a small metal clip just under the top bar. This clip keeps the data pack firmly in place during operation.

When you open the drive door, the clip holds the data pack in place. You can remove the data pack in one of two ways.

Grasp the data pack on the sides and pull it toward you.

Or, press up on the clip to release the data pack. Let the data pack fall against the door, and then remove it.

Remember to physically remove data packs from the drives before you turn power on or off. When the clip is holding the data pack in place, just opening the drive door does not disengage the data pack.



The easiest way to insert a data pack is to lay the data pack against the drive door. Make sure the data pack is centered, the label is facing out, and side of the data pack where the tape shows is down. Then close the door by pushing on both sides of the door simultaneously.

For ADAM™, the ColecoVision® Family Computer System

ColecoVision® is a registered trademark of Coleco Industries, Inc.

Adam™ is a trademark of Coleco Industries, Inc. © 1983 Coleco Industries, Inc. All Rights Reserved.

COLECO

Printed in U.S.A.